

B...N...-QR20-IOL... Inclinometer with IO-Link Interface

Instructions for Use



Contents

1	About the	se instructions	5
	1.1	Target groups	5
	1.2	Explanation of symbols used	5
	1.3	Other documents	5
	1.4	Feedback about these instructions	5
2	Notes on t	the product	6
	2.1	Product identification	6
	2.2	Scope of delivery	6
	2.3	Turck service	7
3	For your s	afety	8
	3.1	Intended use	8
	3.2	Obvious misuse	8
	3.3	General safety instructions	8
4	Product description		
	4.1	Device overview	9
	4.1.1	Indication elements	9
	4.2	Properties and features	9
	4.3	Operating principle	10
	4.4	Functions and operating modes	
	4.4.1 4.4.2	IO-Link mode	
	4.4.2	Measurement axes Temperature measurement	
	4.5	Technical accessories	
5			
6		on	
	6.1	Wiring diagram	
7		oning	
	7.1	Commissioning aid – spirit level	15
8	Operation	1	16
	8.1	LED display	16
9	Setting		
	9.1	Settable functions and features	17
	9.2	Setting via IO-Link	19
10	Troublesh	ooting	20
		nce	
12	-	Returning devices	
	14.1	INCLUITING MCVICC3	4 I

Contents

13	Disposal		21
14	Technical	data	22
	14.1	Technical data B1NQR20-IOLX3-H1141	22
	14.2	Technical data B2NQR20-IOLX3-H1141	23
15	Turck sub	sidiaries – contact information	24

5

1 About these instructions

These instructions for use describe the structure, functions and the use of the product and will help you to operate the product as intended. Read these instructions carefully before using the product. This is to avoid possible damage to persons, property or the device. Retain the instructions for future use during the service life of the product. If the product is passed on, pass on these instructions as well.

1.1 Target groups

These instructions are aimed at qualified personal and must be carefully read by anyone mounting, commissioning, operating, maintaining, dismantling or disposing of the device.

1.2 Explanation of symbols used

The following symbols are used in these instructions:



DANGER

DANGER indicates a dangerous situation with high risk of death or severe injury if not avoided.



WARNING

WARNING indicates a dangerous situation with medium risk of death or severe injury if not avoided.



CALITION

CAUTION indicates a dangerous situation of medium risk which may result in minor or moderate injury if not avoided.



NOTICE

NOTICE indicates a situation which may lead to property damage if not avoided.



NOTE

NOTE indicates tips, recommendations and useful information on specific actions and facts. The notes simplify your work and help you to avoid additional work.

CALL TO ACTION

This symbol denotes actions that the user must carry out.

\Rightarrow

RESULTS OF ACTION

This symbol denotes relevant results of actions.

1.3 Other documents

Besides this document, the following material can be found on the Internet at www.turck.com:

- Data sheet
- Commissioning manual IO-Link devices
- IO-Link parameters manual
- EU Declaration of Conformity (current version)


1.4 Feedback about these instructions

We make every effort to ensure that these instructions are as informative and as clear as possible. If you have any suggestions for improving the design or if some information is missing in the document, please send your suggestions to **techdoc@turck.com**.

2 Notes on the product

2.1 Product identification

These instructions apply to the following inclinometers:



2.2 Scope of delivery

The scope of delivery includes:

- Inclinometer
- Quick Start Guide



2.3 Turck service

Turck supports you with your projects, from initial analysis to the commissioning of your application. The Turck product database under www.turck.com contains software tools for programming, configuration or commissioning, data sheets and CAD files in numerous export formats.

The contact details of Turck subsidiaries worldwide can be found on p. [> 24].

3 For your safety

The product is designed according to state-of-the-art technology. However, residual risks still exist. Observe the following warnings and safety notices to prevent damage to persons and property. Turck accepts no liability for damage caused by failure to observe these warning and safety notices.

3.1 Intended use

The inclinometers of the B...N...-QR20-IOL... series determine the inclination angle in relation to the set center position and output this value as IO-Link process data. The inclinometers also output the temperature as acyclic data.

The devices may only be used as described in these instructions. Any other use is not in accordance with the intended use. Turck accepts no liability for any resulting damage.

3.2 Obvious misuse

■ The devices are not safety components and must not be used for personal or property protection.

3.3 General safety instructions

- The device meets the EMC requirements for industrial areas. When used in residential areas, take measures to avoid radio interference.
- The device may only be assembled, installed, operated, parameterized and maintained by professionally-trained personnel.
- The device may only be used in accordance with applicable national and international regulations, standards and laws.
- Only operate the device within the limits stated in the technical specifications.

4 Product description

The inclinometers of the B...N...-QR20... are provided with a 4-pin M12 plug connector for connecting the sensor cable. The housing is made from plastic and is a fully potted and sealed unit with protection to IP68/IP69K. The sensors are protected from temperature fluctuations.

The device functions can be set via IO-Link.

4.1 Device overview




Fig. 1: Dimensions

mm [Inch]

4.1.1 Indication elements

The B1N... devices are provided with a green and a yellow LED. The green LED indicates the operating voltage and the device status. The yellow LEDs are lit when the spirit level function is active.

The B2N... devices are provided with a green and two yellow LEDs. The green LED indicates the operating voltage and the device status. The yellow LEDs are lit when the spirit level function is active.

4.2 Properties and features

- Angle measurement (1-axis devices): 0...359.9°, resolution 0.01°
- Angle measurement (2-axis devices): ±85°, resolution 0.01°
- Accelerometer cell
- Temperature measurement from -40...+85 °C, resolution 1 °C
- Protection type IP68/IP69K
- Protection against rapid temperature fluctuations
- Communication via IO-Link
- 18...30 VDC
- Spirit level function

The dynamic inclinometers (B...NF...-QR20...) are also provided with the following features:

Gyroscope sensor

4.3 Operating principle

Static inclinometers

The inclinometers use an accelerometer cell for angle measurement and output angles according to the measurement axis or axes. The resolution is 0.01°. The earth's gravity is used as the reference. If the angle in relation to gravity changes, this is detected by the accelerometer cell. The signal is processed and linearized in order to output an angle.

Dynamic inclinometers

The dynamic inclinometers use an accelerometer cell and a gyroscope sensor for angle measurement. The devices output angles according to the measurement axis or axes. The resolution is 0.01°. A fusion algorithm calculates the inclination from the acceleration values and rotation rate values. The fusion algorithm minimizes the effects of vibration and interfering acceleration. The sensor can thus also output a stable signal in dynamic applications. The signal is processed and linearized in order to output an angle.




Fig. 2: Fusion algorithm - minimizing interfering acceleration

Temperature measurement

The temperature is measured by means of an integrated temperature measurement cell. The temperature measured can deviate from the ambient temperature due to different electrical operating conditions in the sensor.

4.4 Functions and operating modes

The devices are provided with an IO-Link interface and can be set via an IO-Link master or FDT frame (e.g. PACTware).

4.4.1 IO-Link mode

The devices must be connected to an IO-Link master for operation in IO-Link mode. If the port is configured in IOL mode, bidirectional IO-Link communication is provided between the IO-Link master and the device. For this the device is integrated in the controller level via an IO-Link master. The communication parameters are exchanged first of all; the cyclic data exchange of the process data (process data objects) then starts.



4.4.2 Measurement axes

The measurement axis of the 1-axis inclinometers covers the angle range from 0...359.9°.




Fig. 3: One measurement axis

The 2-axis inclinometers cover the angle range of $\pm 85^{\circ}$ on two axes in all directions. This results in an unmeasurable angle of 10° per 180°.




Fig. 4: Two measurement axes

4.4.3 Temperature measurement

The inclinometers can output the temperature as acyclic data. The measurement range is -40...+85 °C with a resolution of 1 °C. The measurement has an accuracy of ± 3 °C.

Dimension drawing

4.5 Technical accessories

mension drawing	Type	טו	Description
LED: USB-Mini CH1 (C/Q) CH2 (DI/DO) Error 1 24 M12×1 16	USB-2- IOL-0002	6825482	IO-Link adapter V1.1 with integrated USB interface
M12 x 1 o 15 o 15 M12 x 1 + 11.5 + 42 49.5	RKC4T-2- RSC4T/TXL	6625604	Connection cable, M12 female connector, straight, 3-pin, M12 male connector, straight, 3-pin, cable length: 2 m, sheathing material: PUR, black; cULus approval; other cable lengths and types available, see www.turck.com
	RKC4T-2/TX	L 6625500	Connection cable, M12 female connector, straight, 3-pin, cable

Type

ID

Connection cable, M12 female connector, straight, 3-pin, cable length: 2 m, sheathing material: PVC, black; cULus approval; other cable lengths and types available, see www.turck.com

Description



5 Installing

Depending on the sensor type, the sensors can be installed vertically (B1N...V...) or horizontally (B2N...H...).

In order to implement redundant measurement systems, several sensors can be installed next to each other without any gaps. Multiple sensors have no mutual effect on angle measurement. The maximum tightening torque of the screws is 3 Nm.

- ▶ Clean the installation surface and the surrounding area.
- ▶ Position the potted side of the device on an even surface so that the potting compound is covered.
- ► Fasten the device with two screws.
- After the overhead installation of 2-axis sensors: Carry out the center point teach function.




Fig. 5: B1N...V... – vertical installation




Fig. 6: B2N...H... – horizontal installation

6 Connection

- ► Connect the female connector of the connection cable to the male connector of the sensor.
- ► Connect the open end of the connection cable to the power supply and/or processing units

6.1 Wiring diagram




Fig. 7: Pin assignment




Fig. 8: Wiring diagram



7 Commissioning

After connecting and switching on the power supply, the device is automatically ready for operation.

7.1 Commissioning aid – spirit level

The LEDs act as a spirit level when the inclinometer is aligned. The two yellow LEDs are lit when the position of the inclinometer is within a window of $\pm 0.5^{\circ}$ around the center. The LEDs flash at an increasing frequency the closer the sensor approaches the center position.

One LED flashes with 1-axis movements. Both LEDs flash with 2-axis movements.

The spirit level function can be deactivated via IO-Link. The function is active by default.

8 Operation

8.1 LED display

LED indication	Meaning
Green	Device is operational
Green flashing	IO-Link communication active
Yellow	Spirit level function – Center position reached (±0.5°)
Yellow flashing (increasing frequency)	Spirit level function – Approaching the center position
Yellow flashing (decreasing frequency)	Spirit level function – Leaving the center position
Running light (yellow, green, yellow)	Self-test running



9 Setting

9.1 Settable functions and features

Parameter	Meaning		
Reset device	The command restarts the device. Communication is interrupted momentarily.		
Reset application	The function resets application parameters. Communication is not interrupted and the sensor is switched to a predefined state. Identification parameters are not affected by this command.		
Restore factory setting	The function restores the device to the factory setting. The device is restarted after the reset. Communication is interrupted.		
Spirit level	The spirit level function can be deactivated or activated. The spirit level function is active by default.		
Self-test	The operation of the measurement cell is tested. The three LEDs light up repeatedly in sequence as a running light. Do not move the device or subject it to vibration. The self-test takes approx. 10 s. No process data can be read during the self-test.		
Rotation direction	The function can set the rotation direction of the axis or axes. In the default setting, the process values of the sensors increase to indicate a clockwise direction. The parameter setting enables the increasing process values of the sensors to indicate a counterclockwise direction.		
Determining center position	The function enables the current inclination to be defined as a new measuring range center. The teach function is triggered at bit 0 for the X axis and bit 1 for the Y axis. Teach on 1-axis devices is activated via bit 2. On 2-axis devices, the taught measuring range center must not deviate from the physical zero point by more than 30°.		
Configuring process data	The process data is structured in accordance with the IO-Link Smart Sensor Profile. On 1-axis sensors the angle value is transferred twice and the value is inverted once. A 16-bit value with an accuracy of 0.01° is transferred for the angle of each axis. The angle information can be output as follows: Signed: 16-bit angle information is output for each measurement axis. In Signed representation one bit is used to indicate the sign. The remaining 15 bits represent the angle information in 0.01° increments. The numbers are output as two's complement values. Unsigned: 16-bit angle information with a resolution of 0.01° increments is output for each measurement axis. In the factory setting, this configuration is active.		

Parameter	Meaning
Filters	Different filters can be set for static and dynamic inclinometers. A fusion algorithm calculates the inclination from the acceleration values and rotation rate values. The setting for the filter parameters changes significant areas of the fusion algorithm. The individual sensor data items are weighted differently in the various filters. The different weighting of the sensor data can compensate for disadvantages in the measurement process. Very slow and slow filters can compensate for fast interfering acceleration in the application. The filters are suitable for applications with slow and precise movements, where coarse, external disturbances can occur. Repetitive, rapid movements can accumulate and distort the filter. Very fast and fast filters provide greater accuracy for rapid movements in the application. The filter can be more easily affected by fast interfering acceleration. Repetitive movements cannot accumulate and distort the filter. Static inclinometers: Balanced (factory setting) Slow Dynamic sensors: Balanced Very slow Slow
	FastVery fast (factory setting)



9.2 Setting via IO-Link

The devices can be set via a PC with an FDT frame application (e.g. PACTware). All the required Turck software components can be downloaded via the Turck Software Manager:

- PACTware
- IODD
- DTM for USB-2-IOL-002 IO-Link adapter
- IODD DTM Configurator

The Turck Software Manager can be downloaded free of charge from www.turck.com.

The USB-2-IOL-002 USB IO-Link adapter (ID 6825482) is required for connecting to the PC.

A 3-pin standard sensor cable (e.g. RKC4T-2-RSC4T/TXL, ID 6625604) is required for connecting the sensor to the USB-2-IOL-002 IO-Link adapter.

Further information on setting the devices via IODD with a configuration tool is provided in the IO-Link commissioning manual.

10 Troubleshooting

If the device does not function as expected, first check whether ambient interference is present. If there is no ambient interference present, check the connections of the device for faults.

If there are no faults, there is a device malfunction. In this case, decommission the device and replace it with a new device of the same type.



11 Maintenance

The device is maintenance-free. Clean with a damp cloth if required.

12 Repair

The device must not be repaired by the user. The device must be decommissioned if it is faulty. Observe our return acceptance conditions when returning the device to Turck.

12.1 Returning devices

Returns to Turck can only be accepted if the device has been equipped with a Decontamination declaration enclosed. The decontamination declaration can be downloaded from https://www.turck.de/en/retoure-service-6079.php and must be completely filled in, and affixed securely and weather-proof to the outside of the packaging.

13 Disposal



The devices must be disposed of correctly and must not be included in general household garbage.

14 Technical data

14.1 Technical data B1N...-QR20-IOLX3-H1141

Туре	B1N360V-QR20-IOLX3-H1141	B1NF360V-QR20-IOLX3-H1141		
ID	100025084	100020900		
Measuring range		360°		
Number of measuring axes		1		
Repetition accuracy	≤ 0.2°	≤ 0.1°		
Linearity deviation	< ±0.2 %	< ±0.15 %		
Temperature drift	(0.02°/K		
Resolution		0.01°		
Ambient temperature	-40)+85 °C		
Temperature changes (EN 60068-2-14)	-40+8	-40+85 °C; 20 cycles		
Operating voltage	18.	30 VDC		
Ripple	≤	10 % U _{ss}		
Insulation test voltage	<u> </u>	≤ 0.5 kV		
Wire break / reverse polarity protection		Yes		
Communication protocol	IO-Link			
Current consumption	< 50 mA			
Communication mode	COM 3 (230.4 Kbaud)			
Minimum cycle time	1.3 ms			
Function Pin 4	IO-Link			
Design	Rectangular, QR20			
Dimensions 71.4 × 62.5 × 20 mm		62.5 × 20 mm		
Housing material	Plas	Plastic, Ultem		
Electrical connection	Male con	Male connector, M12 × 1		
Vibration resistance (EN 600068-2-6)	20 g; 5 h/axis; 3 axes			
Shock resistance (EN 60068-2-27)	150 g; 4 ms ½ sine	200 g; 4 ms ½ sine		
Type of protection	IPe	IP68/IP69K		
MTTF	548 years in accordance	548 years in accordance with SN 29500 (Ed. 99) 40 °C		
Operating voltage indication	1×I	1 × LED, green		
Measuring range indication	2×L	2 × LED, yellow		



14.2 Technical data B2N...-QR20-IOLX3-H1141

Туре	B2N85H-QR20-IOLX3-H1141	B2NF85H-QR20-IOLX3-H1141		
ID	100025086	100020901		
Measuring range	±	85°		
Number of measuring axes		2		
Repetition accuracy	≤ 0.2°	≤ 0.1°		
Linearity deviation	< ±0.2 %	< ±0.15 %		
Temperature drift	0.0	0.02°/K		
Resolution	0.	01°		
Ambient temperature	-40	.+85 °C		
Temperature changes (EN 60068-2-14)	-40+85 °	°C; 20 cycles		
Operating voltage	183	30 VDC		
Ripple	≤ 10 % U _{ss}			
Insulation test voltage	≤ 0	.5 kV		
Wire break /	Υ	'es		
reverse polarity protection				
Communication protocol	IO-Link			
Current consumption	< 50	< 50 mA		
Communication mode	COM 3 (230.4 Kbaud)			
Minimum cycle time	1.3 ms			
Function Pin 4	IO-Link			
Design	Rectangular, QR20			
Dimensions	71.4 × 62.5 × 20 mm			
Housing material	lousing material Plastic, Ultem			
Electrical connection	Male conne	Male connector, M12 × 1		
Vibration resistance (EN 600068-2-6)	20 g; 5 h/s	axis; 3 axes		
Shock resistance (EN 60068-2-27)	150 g; 4 ms ½ sine	200 g; 4 ms ½ sine		
Type of protection	IP68/	IP68/IP69K		
MTTF	548 years in accordance v	548 years in accordance with SN 29500 (Ed. 99) 40 °C		
Operating voltage indication	1×LEI	D, green		
Measuring range indication		D, yellow		
		• ,		

15 Turck subsidiaries – contact information

Germany Hans Turck GmbH & Co. KG

Witzlebenstraße 7, 45472 Mülheim an der Ruhr

www.turck.de

Australia Turck Australia Pty Ltd

Building 4, 19-25 Duerdin Street, Notting Hill, 3168 Victoria

www.turck.com.au

Belgium TURCK MULTIPROX

Lion d'Orweg 12, B-9300 Aalst

www.multiprox.be

Brazil Turck do Brasil Automação Ltda.

Rua Anjo Custódio Nr. 42, Jardim Anália Franco, CEP 03358-040 São Paulo

www.turck.com.br

China Turck (Tianjin) Sensor Co. Ltd.

18,4th Xinghuazhi Road, Xiqing Economic Development Area, 300381

Tianjin

www.turck.com.cn

France TURCK BANNER S.A.S.

11 rue de Courtalin Bat C, Magny Le Hongre, F-77703 MARNE LA VALLEE

Cedex 4

www.turckbanner.fr

Great Britain TURCK BANNER LIMITED

Blenheim House, Hurricane Way, GB-SS11 8YT Wickford, Essex

www.turckbanner.co.uk

India TURCK India Automation Pvt. Ltd.

401-403 Aurum Avenue, Survey. No 109 /4, Near Cummins Complex,

Baner-Balewadi Link Rd., 411045 Pune - Maharashtra

www.turck.co.in

Italy TURCK BANNER S.R.L.

Via San Domenico 5, IT-20008 Bareggio (MI)

www.turckbanner.it

Japan TURCK Japan Corporation

Syuuhou Bldg. 6F, 2-13-12, Kanda-Sudacho, Chiyoda-ku, 101-0041 Tokyo

www.turck.ip

Canada Turck Canada Inc.

140 Duffield Drive, CDN-Markham, Ontario L6G 1B5

www.turck.ca

Korea Turck Korea Co, Ltd.

B-509 Gwangmyeong Technopark, 60 Haan-ro, Gwangmyeong-si,

14322 Gyeonggi-Do www.turck.kr

Malaysia Turck Banner Malaysia Sdn Bhd

Unit A-23A-08, Tower A, Pinnacle Petaling Jaya, Jalan Utara C,

46200 Petaling Jaya Selangor www.turckbanner.my



Mexico Turck Comercial, S. de RL de CV

Blvd. Campestre No. 100, Parque Industrial SERVER, C.P. 25350 Arteaga,

Coahuila

www.turck.com.mx

Netherlands Turck B. V.

Ruiterlaan 7, NL-8019 BN Zwolle

www.turck.nl

Austria Turck GmbH

Graumanngasse 7/A5-1, A-1150 Wien

www.turck.at

Poland TURCK sp.z.o.o.

Wrocławska 115, PL-45-836 Opole

www.turck.pl

Romania Turck Automation Romania SRL

Str. Siriului nr. 6-8, Sector 1, RO-014354 Bucuresti

www.turck.ro

Russian TURCK RUS OOO

2-nd Pryadilnaya Street, 1, 105037 Moscow

Federation www.turck.ru

Sweden Turck Sweden Office

Fabriksstråket 9, 433 76 Jonsered

www.turck.se

Singapore TURCK BANNER Singapore Pte. Ltd.

25 International Business Park, #04-75/77 (West Wing) German Centre,

609916 Singapore www.turckbanner.sg

South Africa Turck Banner (Pty) Ltd

Boeing Road East, Bedfordview, ZA-2007 Johannesburg

www.turckbanner.co.za

Czech Republic TURCK s.r.o.

Na Brne 2065, CZ-500 06 Hradec Králové

www.turck.cz

Turkey Turck Otomasyon Ticaret Limited Sirketi

Inönü mah. Kayisdagi c., Yesil Konak Evleri No: 178, A Blok D:4,

34755 Kadiköy/ Istanbul www.turck.com.tr

Hungary TURCK Hungary kft.

Árpád fejedelem útja 26-28., Óbuda Gate, 2. em., H-1023 Budapest

www.turck.hu

USA Turck Inc.

3000 Campus Drive, USA-MN 55441 Minneapolis

www.turck.us

TURCK

Over 30 subsidiaries and over 60 representations worldwide!

