


NI10-M18-Y1X-H1141 Inductive Sensor






Technical data

NI10-M18-Y1X-H1141
40153
10 mm
Non-flush
≤ (0.81 × Sn) mm
St37 = 1; AI = 0.3; stainless steel = 0.7; Ms = 0.4
≤ 2 % of full scale
≤ ±10 %
110 %
2-wire, NAMUR
0.5 kHz
Nom. 8.2 VDC
≥ 2.1 mA
≤ 1.2 mA
KEMA 02 ATEX 1090X
150 nF/150 μH
Ex II 1 G Ex ia IIC T6 Ga/II 1 D Ex ia IIIC T135 °C Da
/ 11 001/1 00 1 0 000 110
$(max. U_i = 20 V, I_i = 20 mA, P_i = 200 mW)$
(max. $U_i = 20 \text{ V}, I_i = 20 \text{ mA}, P_i = 200 \text{ mW})$
(max. U _i = 20 V, I _i = 20 mA, P _i = 200 mW) Threaded barrel, M18 x 1
Threaded barrel, M18 x 1
Threaded barrel, M18 x 1 52 mm

Features

- ■Threaded barrel, M18 x 1
- Chrome-plated brass
- DC 2-wire, nom. 8.2 VDC
- Output acc. to DIN EN 60947-5-6 (NAMUR)
- ■M12 x 1 male connector
- ■ATEX category II 1 G, Ex Zone 0
- ■ATEX category II 1 D, Ex Zone 20
- ■SIL 2 (Low Demand Mode) acc. to IEC 61508, PL c acc. to ISO 13849-1 at HFT0
- SIL 3 (All Demand Mode) acc. to IEC 61508, PL e acc. to ISO 13849-1 with redundant configuration HFT1

Wiring diagram



Functional principle

Inductive sensors detect metal objects contactless and wear-free. For this, they use a high-frequency electromagnetic AC field that interacts with the target. Inductive sensors generate this field via an RLC circuit with a ferrite coil.




Technical data

Electrical connection	Connector, M12 × 1	
Environmental conditions		
Ambient temperature	-25+70 °C	
Vibration resistance	55 Hz (1 mm)	
Shock resistance	30 g (11 ms)	
Protection class	IP67	
MTTF	6198 years acc. to SN 29500 (Ed. 99) 40 °C	
Switching state	LED, Yellow	

Mounting instructions

Mounting instructions/Description




Distance D	3 x B
Distance W	3 x Sn
Distance T	3 x B
Distance S	1.5 x B
Distance G	6 x Sn
Distance N	2 x Sn
Diameter active area B	Ø 18 mm

Accessories

BST-18B 6947214

Mounting clamp for threaded barrel sensors, with dead-stop; material:

PA6





QM-18

Quick-mount bracket with dead-stop; material: Chrome-plated brass. Male thread M24 × 1.5. Note: The switching distance of the proximity switches may change when using quick-mount brackets.

6945102

MW-18

19,7

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

19,1

6945004

Mounting bracket for threaded barrel sensors; material: Stainless steel A2 1.4301 (AISI 304)

BSS-18

Ø 18 26 30 32 40,5 30


6901320

Mounting clamp for smooth and threaded barrel sensors; material: Polypropylene

Accessories

Dimension drawing	Туре	ID	
M12x1 015 \$\infty\$ 14 + 11.5 +	RKC4.221T-2/TEB	6628420	Connection cable, female M12, straight, 2-pin, cable length: 2 m, sheath material: PVC, black; cULus approval; other cable lengths and qualities available, see www.turck.com
0 15 M12 x 1 26.5 32	WKC4.221T-2/TEB	6628427	Connection cable, M12 female connector, angled, 2-pin, cable length: 2 m, jacket material: PVC, black; cULus approval; other cable lengths and qualities available, see www.turck.com

Accessories



Isolating switching amplifier, 2-channel; SIL2 acc. to IEC 61508; Ex-proof version; 2 transistor outputs; input Namur signal; ON/OFF switchable monitoring of wire-break and short-circuit; toggle between NO/NC mode; signal doubling; removable screw terminals; 12.5 mm wide; 24 VDC power supply



Instructions for use

Intended use	This device fulfills Directive 2014/34/EC and is suited for use in areas exposed to explosion hazards according to EN 60079-0:2018 and EN 60079-11:2012. Further it is suited for use in safety-related systems, including SIL2 as per IEC 61508. In order to ensure correct operation to the intended purpose it is required to observe the national regulations and directives.
For use in explosion hazardous areas conform to classification	II 1 G and II 1 D (Group II, Category 1 G, electrical equipment for gaseous atmospheres and category 1 D, electrical equipment for dust atmospheres).
Marking (see device or technical data sheet)	Ex II 1 G and Ex ia IIC T6 Ga and Ex II 1 D Ex ia IIIC T135 °C Da acc. to EN 60079-0, -11
Local admissible ambient temperature	-25+70 °C
Installation/Commissioning	These devices may only be installed, connected and operated by trained and qualified staff. Qualified staff must have knowledge of protection classes, directives and regulations concerning electrical equipment designed for use in explosion hazardous areas. Please verify that the classification and the marking on the device comply with the actual application conditions.
	This device is only suited for connection to approved Exi circuits according to EN 60079-0 and EN 60079-11. Please observe the maximum admissible electrical values. After connection to other circuits the sensor may no longer be used in Exi installations. When interconnected to (associated) electrical equipment, it is required to perform the "Proof of intrinsic safety" (EN60079-14). Attention! When used in safety systems, all content of the security manual must be observed.
Installation and mounting instructions	Avoid static charging of cables and plastic devices. Please only clean the device with a damp cloth. Do not install the device in a dust flow and avoid build-up of dust deposits on the device. If the devices and the cable could be subject to mechanical damage, they must be protected accordingly. They must also be shielded against strong electro-magnetic fields. The pin configuration and the electrical specifications can be taken from the device marking or the technical data sheet.
Service/Maintenance	Repairs are not possible. The approval expires if the device is repaired or modified by a person other than the manufacturer. The most important data from the approval are listed.